ETC® Console Shortcut Keys

Eos Family v2.2.0

Note: *Keyboard **[Scroll Lock]** must be OFF*

To enable Eos functions on Mac Function keys:

Step 1: Open Systems Preferences

Step 2: Go into the Keyboard section

Step 3: Enable the "Use all F1, F2,etc... keys as standard function keys" setting

Console Key	PC
Shortcut List for Help	;
	?
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
. (decimal)	. (decimal)
- (minus)	- (minus)
+ (plus)	=
	+
+%	Shift Page Up
+% (Mac)	*Shift Fn Up Arrow*
-%	Shift Page Down
-% (Mac)	*Shift Fn Down Arrow*
/	/
About	Control /
Address/Dimmer	Alt A
All NPs	Control A
Assert	Shift A
Assert (Playback)	Shift S
At	A
	@
	*
Beam Filter	Control B
Beam Palette	Alt B
Blind	F3
Block	Shift B
Capture	Control P
Channel Filter	Shift C
CIA Hide	F5
Clear	Backspace
Color Filter	Control C

Console Key	PC
Color Palette	Alt C
Copy To	Shift P
Cue	Q
Cue Only/Track	X
Data	Shift D
Delay	D
Delete	Delete
Delete (Mac)	*Fn Delete*
Displays	F9
Effect	Alt E
Encoder Display (Gio)	Alt F5
Encoder Page Focus	Control 5
Encoder Page Color	Control 6
Encoder Page Image	Control 7
Encoder Page Form	Control 8
Encoder Page Shutter	Control 9
Encoder Page Custom	Control 0 (zero)
Enter	Enter
Escape	Escape
Expand	F11
Fader Independent	Shift I
Fader Pages	] (right bracket)
Fan	Alt. (decimal)
Filter Mode (CIA)	‘ (apostrophe)
Flexi-Channel	F8
Focus Filter	Control F
Focus Palette	Alt F
Follow/Hang	Control H
Format	F4
Frame	Shift F
Freeze	Shift Z
Full	F
Go	Spacebar
	Control G
Go To Cue	Shift G
Go To Cue Zero	Alt Z
Group	G
Help	F1

Corporate Headquarters ■ 3031 Pleasant View Road, P.O. Box 620979, Middleton, Wisconsin 53562-0979 USA ■ Tel +608 831 4116 ■ Fax +608 836 1736
London, UK ■ Unit 26-28, Victoria Industrial Estate, Victoria Road, London W3 6UU, UK ■ Tel +44 (0)20 8896 1000 ■ Fax +44 (0)20 8896 2000
Rome, IT ■ Via Pieve Torina, 48, 00156 Rome, Italy ■ Tel +39 (06) 32 111 683 ■ Fax +44 (0) 20 8752 8486
Holzkirchen, DE ■ Ohmstrasse 3, 83607 Holzkirchen, Germany ■ Tel +49 (80 24) 47 00-0 ■ Fax +49 (80 24) 47 00-3 00
Hong Kong ■ Rm 1801, 18/F, Tower 1 Phase 1, Enterprise Square, 9 Sheung Yuet Road, Kowloon Bay, Kowloon, Hong Kong ■ Tel +852 2799 1220 ■ Fax +852 2799 9325
Service: (Americas) service@etcconnect.com ■ (UK) service@etceurope.com ■ (DE) techserv-hoki@etcconnect.com ■ (Asia) service@etcasia.com
Web: www.etcconnect.com ■ Copyright © 2014 ETC. All Rights Reserved. ■ Product information and specifications subject to change.
■ ETC intends this document to be provided in its entirety.

ETC Console Shortcut Keys

Eos Family v2.2.0

High / Low	\
Home	Home
Home (Mac)	*Fn Left Arrow*
Intensity Filter	Control I
Intensity Palette	Alt I
Label	B
Last	Page Up
Last (Mac)	*Fn Up Arrow*
Learn	L
Level	V
Live	F2
Load	Control F2
	Control 2
Macro	Shift F8
	Control 4
Manual Override	Shift M
Magic Sheet	Control S
Mark	M
Mirror, Start	Alt M
Mirror, Stop	Alt X
ML Controls	Alt F5
More Softkeys	Shift F7
	Alt 7
Next	Page Down
Next (Mac)	*Fn Down Arrow*
Off	Shift O
Offset	Control O
Out	O
Page Left	Left Arrow
Page Right	Right Arrow
Page Up	Up Arrow
Page Down	Down Arrow
Parameters (CIA)	E
Park	K
Park Display	Alt K
Part	P
Patch	Alt F2
Pixelmap	Alt P
Preset	Alt S
Query	Y
Rate	Shift R
Recall From	Shift L
Record	R
Record Only	W
Release	Shift U
Rem Dim	H
Scroll Lock	Alt L
Select	F6
Select Active	Control V
Select Last	Control L
Select Manual	Control M
Setup	Alt F3

Shift	Z
Snapshot	Shift F9
	Control 1
Sneak	N
Softkey 1	Shift F1
	Alt 1
Softkey 2	Shift F2
	Alt 2
Softkey 3	Shift F3
	Alt 3
Softkey 4	Shift F4
	Alt 4
Softkey 5	Shift F5
	Alt 5
Softkey 6	Shift F6
	Alt 6
Spacebar Disable	Alt G
Stop/Back	Control F3
	Control 3
Stop Effect	Shift E
Submaster	S
Tab	Tab
Time	I
Timing Disable	Shift T
Time (Displays)	Control T
Thru	T
Trace	J
Undo	C
Update	U
Virtual Keyboard	Control K

ETC Console Shortcut Keys

Eos Family v2.2.0

Shell Shortcut Keys	
Shell Key	**PC**
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
. (decimal)	. (decimal)
- (minus)	- (minus)
+ (plus)	=
/	/
Arrow, Down	Arrow, Down
Arrow, Left	Arrow, Left
Arrow, Right	Arrow, Right
Arrow, Up	Arrow, Up
Back	Esc
Clear	Backspace
Delete	Delete
Enter	Enter
Escape	Esc
Select	Return